

FULL 100



Free Visual Safety Report

Free Wash and Vac

Free Hybrid Health Check (model dependant)

Check all pedals and components

Check steering wheel

Check horn

Check washers

Check wipers

Check interior lights

Check exterior lights

Check warning lights

Change air conditioning/pollen filter (model dependant)

Check seat belts

Check floor mat security

Drain engine oil

Replace oil filter

Refill engine oil

Check levels and refill as required

Inspect suspension

Inspect steering

Inspect tyres

Inspect wheels

Check and adjust tyre pressures

Inspect spare wheel / spare saver / tyre repair kit (model dependant)

Inspect brake pads and discs

Torque tighten wheel nuts

Check radiator and condenser

Inspect drive belts

Check 12v battery

Recheck for fluid leaks - underside and engine bay

Recheck all levels

Reset service lights or monitor as required

Set next service date in media system

Check alarm and immobiliser

Check and adjust gear cables (model dependant)

Inspect glass and light lenses

Replace battery(s) in locking remote(s)

Check and inspect suspension ball free play

Inspect and where necessary replace front and rear differential oils (model dependant)

Inspect drive shaft boots

Inspect suspension ball joints and dust covers

Inspect fuel and brake pipes

Inspect exhaust pipes and mountings

Inspect wheel bearings

Inspect hand brake

Inspect clutch fluid (model dependant)*

Inspect charcoal canister (model dependant)

Check fuel cap & lines

4-wheel alignment check - extra charge for adjustment

Replace brake fluid (every two years)

Inspect air filter - replace as required (model dependant)

Replace engine coolant (model dependant)

Check transmission oil - replace as required (model dependant)

Check transfer/differential box oil - replace as required (model dependant)

Lubricate prop shat joints (model dependant)

Tighten prop shaft bolts (model dependant)

Conduct diesel smoke test (model dependant)

Replace timing belt (model dependant)*

Clean airflow meter

Check valve clearances

Replace hybrid inverter coolant (model dependant)

Replace diesel vacuum pump (model dependant)*
